

Erie Metal Specialties, Inc. 13311 Main Road Akron, NY 14001 Phone: 716-542-3991 Website: www.eriemetal.com E-Mail: sales@eriemetal.com

ENBW Series Expansion Joint Systems

Prepare for Installation


- 1. Locate the packing slip(s) and shop drawings.
- 2. Verify that all products listed on the packing slip are included in the package.
- 3. Check the products for damage. If products are damaged, report a freight claim immediately and leave the products in their packaging. If you sign for products without reporting damage you waive your right to a freight claim and will be responsible for their replacement cost.
- 4. Read the instructions thoroughly before beginning installation.

Tools List:

- Drill
- Level

Chalk Line

Chop Saw




Model	P/N
GASKET	1309

Model	"A"	P/N
ENBW-100	1.77	29465
ENBW-200	2.77	29467




Model	"A"	P/N
ENBW-100	1.71	29466
ENBW-200	2.71	29468




Model	"A"	P/N
ENBW-100	2.19	29473
ENBW-200	3.69	29474


Parts List:




Installation:




1. Position the bottom plate flush with the inside surface of the joint opening. Field drill holes thru the bottom plate and stud spaced 18 inches on center. After the holes have been drilled, fasten the bottom plate to the wall with drywall screws (by others). If required, fire barrier and moisture barrier should be installed at this time.




2. Cut Gasket material to length and push the gasket into the groove on the aluminum top plate.



3. Place center plate into position against the adjacent bottom plates.



4. Align aluminum top plate with gasket material in front of base extrusion. Using the palm of your hand, gently tap aluminum top plate onto the aluminum base extrusion. It should click into place all along the length of the top plate. Repeat on opposite side. When installing, exercise care not to damage top plate.



Operation:

Expansion joints are designed and built for years of dependable service.

Maintenance:

- 1. Expansion Joints should be cleaned routinely.
- 2. Exposed surfaces can be cleaned with a mild water-based cleaning solution. Wipe clean with a sponge or soft cloth.
- 3. <u>Do not use steel wool or powdered abrasive cleaners</u> as they will scratch the aluminum surface.
- 4. If any questions arise during the operation or maintenance of the products, please feel free to call our office for support.

ENBW-###W Series Expansion Joint Systems (Corner)

Prepare for Installation

- 1. Locate the packing slip(s) and shop drawings.
- 2. Verify that all products listed on the packing slip are included in the package.
- 3. Check the products for damage. If products are damaged, report a freight claim immediately and leave the products in their packaging. If you sign for products without reporting damage you waive your right to a freight claim and will be responsible for their replacement cost.
- 4. Read the instructions thoroughly before beginning installation.

Tools List:


- Drill
- Level

Chalk Line

Chop Saw

Parts List:


Ö




Model	P/N
GASKET	1309

Model

Model	"A"	P/N
ENBW-100W	1.77	29465
ENBW-200W	2.77	29467






ENBW-100W	1.71	29466
ENBW-200W	2.71	29468
<u></u>		•


"A'

P/N


Model	"A"	P/N
ENBW-100W	1.55	29475
ENBW-200W	3.05	29476




Installation:




1. Position the bottom plate flush with the inside surface of the joint opening. Field drill holes thru the base extrusion and stud spaced 18 inches on center. After the holes have been drilled, fasten the base extrusion to the wall with drywall screws (by others). If required, fire barrier and moisture barrier should be installed at this time.




2. Cut Gasket material to length and push the gasket into the groove on the top plate.



3. Place center slide plate into position against the adjacent bottom plates.



4. Align aluminum top plate with gasket material in front of bottom plate. Using the palm of your hand, gently tap aluminum top plate onto the aluminum bottom plate. It should click into place all along the length of the top plate. Repeat on opposite side. When installing, exercise care not to damage top plate.



Operation:

Expansion joints are designed and built for years of dependable service.

Maintenance:

- 1. Expansion Joints should be cleaned routinely.
- 2. Exposed surfaces can be cleaned with a mild water-based cleaning solution. Wipe clean with a sponge or soft cloth.
- 3. Do not use steel wool or powdered abrasive cleaners as they will scratch the aluminum surface.
- 4. If any questions arise during the operation or maintenance of the products, please feel free to call for assistance (716-542-3991)